





beleuchteter Wagen



Tür an der Unterseite greifen und vom Wagenkasten nach außen ziehen. Tür zur Seite schieben.

Pull the bottom of the door away from the car body. Slide the door sideways to open.


Éloigner le bas de la porte de la caisse de la voiture. Glisser la porte de côté pour ouvrir.



Deur aan de onderzijde beetpakken en vanaf de rijtuigwand naar buiten trekken. Deur opzij schuiven.

Tomar la puerta por el lado inferior y tirar hacia fuera de la caja del coche. Empujar la puerta hacia un lado.

Afferrare la porta sul lato inferiore e tirarla verso l'esterno dalla cassa della carrozza. Fare scorrere la porta sul lato.



Lichtschalter an der Unterseite des Wagens

Light switch on the underside of the trolley

Interrupteur d'éclairage sur la face inférieure du chariot

Lichtschakelaar aan de onderkant van de trolley

Interruptor de luz en la parte inferior del carro

Interruttore luci sul lato inferiore del carrello

Gebr. Märklin & Cie. GmbH
Stuttgarter Str. 55 - 57
73033 Göppingen
Germany
www.maerklin.com




www.maerklin.com/en/imprint.html

135699/1221/Sm5Ef
Änderungen vorbehalten
© Gebr. Märklin & Cie. GmbH